49381977 / HI-VIS SHELL JACKET


PRODUCT DIMENSIONS

| Measurements in inches | s | М | L | XL | XXL | XXXL | 4XL | 5XL |
|------------------------|--------|--------|--------|--------|--------|--------|--------|--------|
| Chest width | 24 | 25 1/4 | 26 3/8 | 27 1/2 | 28 3/4 | 29 7/8 | 31 1/8 | 32 1/4 |
| Garment length | 30 3/4 | 31 1/2 | 32 1/4 | 33 1/8 | 33 7/8 | 34 5/8 | 35 3/8 | 36 1/4 |
| Sleeve length | 27 1/8 | 27 3/8 | 27 1/2 | 273/4 | 28 | 28 1/8 | 28 3/8 | 28 1/2 |

MEASURE YOUR FAVORITE GARMENT

If you are unsure of which size to choose, measure your favorite garment at home and compare it with the measurements of the garment in the table above. Choose the size that matches best. Below you will find a description of how we measure our garments.

Keep in mind that even industrial sewing is a craft that is carried out in many steps, therefore there is always a tolerance for measurement deviations.



HOW TO MEASURE

A: Sleeve lengt

Lay the garment flat. Measure from the shoulder to the end of the sleeve.

B: Chest

Lay the garment flat. Measure from armpit to armpit.

C: Bottom width, circumreference

Lay the garment flat. Measure from edge to edge at the bottom of the garment.

D: Garment length

Lay the garment flat. Measure the length from the shoulder down to where the garment (Back) ends.