



The following table from the U.S. Department of Energy (Occupational Safety and Health Technical Reference Manual) rates various gloves as being protective against specific chemicals

CHEMICAL	NEOPRENE	LATEX/RUBBER	BUTYL	NITRILE
Acetaldehyde*	VG	G	VG	G
Acetic acid	VG	VG	VG	VG
Acetone*	G	VG	VG	Р
Ammonium hydroxide	VG	VG	VG	VG
Amy acetate*	F	Р	F	Р
Aniline	G	F	F	Р
Benzaldehyde*	F	F	G	G
Benzene*	Р	Р	Р	F
Butyl acetate	G	F	F	Р
Butyl alcohol	VG	VG	VG	VG
Carbon disulfide	F	F	F	F
Carbon tetrachloride*	F	Р	Р	G
Castor oil	F	Р	F	VG
Chlorobenzene*	F	Р	F	Р
Chloroform*	G	Р	Р	F
Chloronaphthalene	F	Р	F	F
Chromic acid (50%)	F	Р	F	F
Citric acid (10%)	VG	VG	VG	VG
Cyclohexanol	G	F	G	VG
Dibutyl phthalate*	G	Р	G	G
Diesel fuel	G	Р	Р	VG
Diisobutyl ketone	Р	F	G	Р
Dimethylformamide	F	F	G	G







CHEMICAL	NEOPRENE	LATEX/RUBBER	BUTYL	NITRILE
Dioctyl phthalate	G	Р	F	VG
Dioxane	VG	G	G	G
Epoxy resins, dry	VG	VG	VG	VG
Ethyl acetate*	G	F	G	F
Ethyl alcohol	VG	VG	VG	VG
Ethyl ether*	VG	G	VG	G
Ethylene dichloride*	F	Р	F	Р
Ethylene glycol	VG	VG	VG	VG
Formaldehyde	VG	VG	VG	VG
Formic acid	VG	VG	VG	VG
Freon 11	G	Р	F	G
Freon 12	G	Р	F	G
Freon 21	G	Р	F	G
Freon 22	G	Р	F	G
Furfural*	G	G	G	G
Gasoline, leaded	G	Р	F	VG
Gasoline, unleaded	G	Р	F	VG
Glycerin	VG	VG	VG	VG
Hexane	F	Р	Р	G
Hydrazine (65%)	F	G	G	G
Hydrochloric acid	VG	G	G	G
Hydrofluoric acid (48%)	VG	G	G	G
Hydrogen peroxide (30%)	G	G	G	G
Hydroquinone	G	G	G	F
sooctane	F	P	Р	VG







CHEMICAL	NEOPRENE	LATEX/RUBBER	BUTYL	NITRILE
Kerosene	VG	F	F	VG
Ketones	G	VG	VG	Р
Lacquer thinners	G	F	F	Р
Lactic acid (85%)	VG	VG	VG	VG
Lauric acid (36%)	VG	F	VG	VG
Lineolic acid	VG	Р	F	G
Linseed oil	VG	Р	F	VG
Maleic acid	VG	VG	VG	VG
Methyl alcohol	VG	VG	VG	VG
Methylamine	F	F	G	G
Methyl bromide	G	F	G	F
Methyl chloride*	Р	Р	Р	Р
Methyl ethyl ketone*	G	G	VG	Р
Methyl isobutyl ketone*	F	F	VG	Р
Methyl metharcrylate	G	G	VG	F
Monoethanolamine	VG	G	VG	VG
Morpholine	VG	VG	VG	G
Naphthalene	G	F	F	G
Napthas, aliphatic	VG	F	F	VG
Napthas, aromatic	G	Р	Р	G
Nitric acid*	G	F	F	F
Nitric acid, red and white fuming	Р	Р	Р	P
Nitromethane (95.5%)*	F	Р	F	F
Nitropropane (95.5%)	F	Р	F	F
Octyl alcohol	VG	VG	VG	VG







CHEMICAL	NEOPRENE	LATEX/RUBBER	BUTYL	NITRILE
Oleic acid	VG	F	G	VG
Oxalic acid	VG	VG	VG	VG
Palmitic acid	VG	VG	VG	VG
Perchloric acid (60%)	VG	F	G	G
Perchloroethylene	F	Р	Р	G
Petroleum distillates (naphtha)	G	Р	Р	VG
Phenol	VG	F	G	F
Phosphoric acid	VG	G	VG	VG
Potassium hydroxide	VG	VG	VG	VG
Propyl acetate	G	F	G	F
Propyl alcohol	VG	VG	VG	VG
Propyl alcohol (iso)	VG	VG	VG	VG
Sodium hydroxide	VG	VG	VG	VG
Styrene	Р	Р	Р	F
Styrene (100%)	Р	Р	Р	F
Sulfuric acid	G	G	G	G
Tannic acid (65)	VG	VG	VG	VG
Tetrahydrofuran	Р	F	F	F
Toluene*	F	Р	Р	F
Toluene diisocyanate (TDI)	F	G	G	F
Trichloroethylene*	F	F	Р	G
Triethanolamine (85%)	VG	G	G	VG
Tung oil	VG	Р	F	VG
Turpentine	G	F	F	VG
Xylene*	Р	Р	Р	F

